

EVCC300 Charger checker Electric Vehicle Charger Checker



- Checks mode 2 and single phase mode 3 (level 1 and two phase level 2) chargers
- Checks chargers with SAE J1772 Type 1 and Type 2 connectors
- Performs four EV charger safety checks
- Performs four EV charger operation checks
- Checks to see if nuisance tripping or RCD/GFCI is likely to occur
- Reads control pilot state response from EV Charger to IEC61852-1

DESCRIPTION

The new EVCC300 introduces a new and convenient way of checking Electric Vehicle charge points. A simple all in one concept provides an easy to use solution to check both the safety and operation of mode 2 and single phase mode 3 (level 1 and two phase level 2) EV chargers. The instrument is ideal for those wishing to perform a check on an EV charger following manufacture, installation or repair, or just part of a maintenance schedule / inspection.

FEATURES AND BENEFITS

Four important safety checks:

- 1. PE touch pad to check ground connection and hazardous voltages
- 2. PE resistance (RPE) test to check any exposed metal work is properly grounded / earthed
- 3. Touch voltage test to ensure the charger ground / earth does not rise to a hazardous level when charger output is on
- 4. RCD / GFCI protection check by timing the device tripping speed. This test causes a calibrated ground / earth leakage current appropriate to the trip rating of the device to flow and time how long it takes for the device to break the supply. If an RCD / GFCI was to take too long to trip it would not protect the charger user from electrocution, so it is an important safety check

■ Nuisance charger supply tripping check.

This test will help determine whether the EV charger user is likely to experience nuisance tripping of the RCD or GFCI. The EVCC300 slowly increases ground / earth leakage current until the protective device trips to ensure it trips at the correct leakage current level. If the leakage current that trips the device is too low it will indicate either an issue with the device or there is already a high level of leakage present.

Four key EV charger operation checks:

- Proximity detection operation check. The EVCC300
 can check that proximity is detected and also whether,
 when testing a type 1 connection, that latching
 detection has worked correctly
- 2. Control pilot operation check. Not only can the EVCC300 set CP states to operate the EV charger, the instrument can read the response state of the charger. The codes A, B, C, D, E and F can be set by the EVCC300 and the response of the charger displayed on the instruments colour display. The charger PC state is displayed together with the chargers indicated maximum charge current, all to IEC61851-1 requirements
- 3. Control pilot signal check. The EVCC300 measures the CP signal Voltage, Frequency and Duty cycle. Repeated measurements will highlight instability in the signal.
- 4. EV charger output check. The EVCC300 measures the output voltage and frequency of the EV charger when charging in is in progress. When appropriate the EVCC300 also checks for correct L – N supply polarity.



EVCC300 Charger checker

Electric Vehicle Charger Checker

APPLICATIONS

- Safety and operation checks on mode 2 and single phase mode 3 charge points (level 1 and two phase level 2 in the USA)
- Connects to SAE J1772 Type 1 and Type 2 charger connectors only
- Checking charger following installation before hand over to customer
- Checking charger as part of a regular maintenance schedule
- Checking charger following repair before hand over to customer
- Checking chargers following manufacturing as part of a QA inspection
- Fault checking when customer reports charger issues to car dealership/service centre

SPECIFICATIONS

EVSE STANDARD IEC 61851-1:2017

EVSE SUPPLY OPTIONS (set in settings)

230 V single phase
 120 V single phase
 208 V two phase

4. 240 V tow phase

SUPPLY MEASUREMENT

Voltage range 5 V to 300 V

Voltage resolution 1 V

Voltage accuracy $\pm 5\% \pm 2$ digits

Voltage measurement L to N, L to PE and N to PE

Reverse polarity indication L to N, for single phase option only

Frequency range 45 Hz to 65 Hz

Frequency resolution 1 Hz
Frequency accuracy ± 1 digit

EVSE INTERFACE (EV charger function) tests:

1. Proximity detection (PP) states

Read only

No proximity

Proximity detected, unlatched Proximity detected, latched

2. Control pilot (CP)

Set and read states: State A – Disconnected

State B – Connected State C – Charging

State D – Charging without

ventilation

State E – CP short to PE

Read only state State F – EVSE charger fault

condition

Maximum voltage ± 14 V

Frequency range 940 Hz to 1040 Hz

Duty cycle range 8% to 97%

Maximum charging current indication according to

IEC 61851-1:2017, tables A.7 and A.8

RESISTANCE OF EARTH PROTECTIVE CONDUCTOR (RPE)

Test current: 200 mA Resistance range: 0 to 10 Ω Resistance resolution: 0.01 Ω

Resistance accuracy: $\pm 5\% \pm 2$ digits

RCD/GFCI TESTS:

Trip time accuracy: $\pm 1\% \pm 1 \text{ ms}$

Trip current accuracy: $\pm 3\%$ (apply to all RCD/GFCI tests)

PERSONAL PROTECTION TESTS, 230 V SINGLE PHASE:

1. RCD 30 mA ac TEST

Test current: 31.5 mA AC

(5% above nominal trip current)

Max. test time: 300 ms

Polarity selection: 0° and 180° of an input sine wave

2. RCD 6 mA dc TEST

Test current ramp up at rate of 6 mA in 2.5 s,

then held at 6 mA DC

Ramp polarity positive and negative ramp

Max. test time: 12.5 s

Polarity selection: 0° and 180° of an input sine wave

PERSONAL PROTECTION TESTS, 120 V SINGLE PHASE / 240 V TWO PHASE

1. GFCI/CCID 5 mA ac test

Test current: 6 mA AC
Max. test time: 5.59 s

Polarity selection: 0° and 180° of an input sine wave

2. GFCI/CCID 20 mA ac test

Test current: 21 mA AC

(5% above nominal trip current)

Max. test time: 5.59 s

Polarity selection: 0° and 180° of an input sine wave

NUISANCE TRIPPING TESTS, 230 V SINGLE PHASE

1. RCD ac ramp test

Test current AC current ramp up to

30 mA in 2 mA steps

Step time: 300 ms
Max. test time: 4.5 s

EVCC300 Charger checker

Electric Vehicle Charger Checker

2. RCD dc ramp test

Test current ramp up at rate of 6 mA in 2.5 s,

then held at 3 mA DC.

Max. test time: 11.25 s

NUISANCE TRIPPING TESTS, 120 V SINGLE PHASE / 240 V TWO PHASE

1. GFCI/CCID 5 mA AC test

Test current AC current ramp up to 6 mA

in 0.5 mA steps

Step time: 100 ms
Max. test time: 1.2 s

2. GFCI/CCID 20 mA AC test

Test current AC current ramp up to

20 mA in 1 mA steps

Step time: 100 ms Max. test time: 2 s

TOUCH VOLTAGE TEST

Options: 25 V or 50 V limit

Test current typically 1/3 of RCD nominal test current

TOUCH CONTACT PAD TEST

Dangerous voltage indication at PE conductor

POWER SUPPLY

Battery: Four AA cells

CONNECTIONS

Type 2 male – main test connection

4 mm shrouded socket on base of handle – RPE test return

connection

LANGUAGES

User Interface: English, French, German and

Spanish

User guide: English, French, German and

Spanish

DIMENSIONS AND WEIGHTS

Dimensions are (L x H x W)

24 x 18 x 8.6 cm.

Weight (without batteries)

583 g

SAFETY

Standards IEC 61010-1:2010

Safety category CATII 300 V

ENVIRONMENT

Operational temperature 0 °C to 40 °C

Storage temperature -10 °C to 70 °C

Operating humidity 90% R.H. at +40 °C max

Maximum altitude: 2000 m

Dust and moisture ingress: IP40 to IEC60529 in use

Description	Part number	Additional Accessories	Part number
EVCC300	1013-576	Continuity/earth bond lead	1001-233

SALES OFFICE

Megger Limited Archcliffe Road Dover CT17 9EN England T +44 (0) 1304 502101

E UKsales@megger.com

EVCC300_DS_en_V02

www.megger.com ISO 9001

The word 'Megger' is a registered trademark

