


PS500



Quick Operation Guide



Switch On




Switch Off



Backlight On

Max

Min



Confidence Signal


Every 15s



Manual Datalog




Pump





Alarm Indicators





Gas Alarm Acknowledge





Self Test




Flow Fault



Zero Fault



Calibration Overdue



Battery Life



Charging

