


EtherScope[®] nXG



The EtherScope[®] nXG is a rugged, hand-held tool for testing and analyzing copper, fiber, and Wi-Fi networks. This Portable Network Expert features applications developed by NetAlly for network discovery, measurement, and validation.



AutoTest – Verify your network layers 1 through 7 in seconds.



Capture – Record Wired or Wi-Fi frames with filters.



Wi-Fi – Identify APs, SSIDs, clients, and channels from your location.



AirMapper™ – Perform Wi-Fi site surveys and generate heat maps in Link-Live.



iPerf – Test Wired or Wi-Fi connections to a NetAlly Test Accessory or server.



LANBERT™ – Qualify layer 1 copper/fiber media for error free operation.



Ping/TCP – Validate and monitor responsiveness and connectivity.



Discovery – Identify and analyze all devices on your network.



Path Analysis – Trace Layer 2 and 3 routes.



Performance – Measure 10G line rate with multiple streams.



Link-Live – Upload, manage, and analyze results and data in the Cloud.



Cable Test – Determine length, status, and wiremapping, and employ toning.

Power Up and Connect

Your EtherScope nXG includes a USB-C 15V/3A (45 W) power adapter. Other USB-C power adapters are not supported.

- To begin charging the internal battery, plug the included power adapter into the left-side USB-C port. The unit will fully charge in 2-3 hours via AC power. The power LED button turns red when the unit is charging and off at full charge. Press it briefly to view the battery level on the screen.

Start Testing

When you power on the EtherScope nXG, the AutoTest, Discovery, and Wi-Fi apps begin collecting available wired and Wi-Fi data from your network in the background. Open Discovery or Wi-Fi to view discovered devices on your networks, or open AutoTest and run test “Profiles.” An AutoTest Profile is a series of tests and their saved connection and threshold settings. After running a profile, you can tap the individual test cards to view more details, retest, or open other apps for further analysis.

For more options, tap the Floating Action Button (FAB)  at the lower right corner of app screens.

Tap the Menu button  or Settings button  to configure apps and tests for your network.

To return Home and open other apps, tap the home button  at the bottom of the screen.

Navigate the User Interface

The EtherScope nXG touchscreen supports many of the operations typical of any mobile device. Use dragging and swiping motions to navigate through apps, open side menus, drag down the notification panel from the top, and drag up the Apps screen from the bottom of the Home screen.

The main navigation buttons are always at the very bottom of the touchscreen:

-  The back icon returns to the previous screen.
-  The circle icon opens the Home screen.
-  The square icon displays your recently used applications for easily switching between them.

You can add third-party apps from the NetAlly App Store. To download these curated apps, first visit our Link-Live website, and claim your unit.

Connect to Link-Live

Link-Live Cloud Service is a free, online system to collect, organize, analyze, and report on your test results. AutoTest data is automatically uploaded once your EtherScope nXG is “claimed” to Link-Live and properly configured.

To start, create a user account at Link-Live.com, and sign in. The first time you sign in, a pop-up window prompts you to claim a device. If you already have other devices claimed, go to the Units page from the left-side drawer, and select the Claim Unit button at the lower right corner of the page. 

Then, select the EtherScope nXG image.

On your EtherScope nXG Home screen, open the Link-Live app , and tap CLAIM NOW.

To learn more about Link-Live.com and view video tutorials, open Support from the left-side navigation drawer on the website.

Other Helpful URLs

NetAlly.com/Products/EtherScopenXG for product information

support.netally.com/Login to register your product

NetAlly.com/Support for technical assistance


PN 770-000034
06/2023
For software v2.2+