

Sauter GmbH

Ziegelei 1 D-72336 Balingen E-Mail: info@sauter.eu Tel: +49-[0]7433-9933-199 Fax: +49-[0]7433-9933-149 Internet: www.kern-sohn.com

Instruction Manual TD_US

DIGITAL THICKNESS GAUGE



Model: TD 225-0.1 US

Table of contents

- 1. Features
- 2. Specifications
- 3. Front panel description
- 4. Material selection
- 5. Calibration
- 6. Measuring procedure
- 7. Measuring by velocity setting
- 8. Battery replacement
 9. Declaration of conformity
-
- Annotation: It is strongly recommended to calibrate the new instrument before the first use, as described in paragraph 5. By doing this it will be achieved a much better measurement result right from the start.

1. Features

- * The exclusive Micro- computer LSI offers high measurement accuracy.
- * The instrument offers high power of emission and a wide spectrum of receiving sensitivity.
 Sensors of different frequencies can be identified.
 Rough surfaces, even cast iron, can be measured.
 It is used in almost all kinds of industries.
- * Convenient to measure the thickness of many materials, e.g. steel, cast iron, aluminium, red copper, brass, zinc, quarz glass, Polyethylen, PVC, grey cast iron, nodular cast iron.
- * Automatic power-off to preserve batteries.
- * Date transfer to PC possible. Cable and software can be obtained as optional accessory.

2. Specifications

Display: 4 digits, 10mm LCD

Range: 1.0 to 200mm (45# steel)

Resolution: 0.1mm / 0.001 inch

Accuracy: ± (0.5%n+0.1) Sound velocity: 500 to 9000m/s

Power supply: 4x1.5V AAA (UM-4) battery

Operating conditions: Temperature: 0 to 50°C

Humidity: <80%

Size: 120 x 62 x 30mm (4.7 x 2.4 x 1.2 inch)

Weight: about 164g (not including batteries)

Accessories: Carrying case Operation manual Ultrasonic sensor

3. Front panel description



- 3-1 Sensor plug
- 3-2 Display
- 3-3 mm/ inch key
- 3-4 Power-key
- 3-5 Material selection key
- 3-6 Plus-key
- 3-7 Ultrasonic sensor
- 3-8 Calibration key
- 3-9 Minus-key
- 3-10 Battery compartment/ cover
- 3-11 Coupling indicator
- 3-12 Base plate
- 3-13 Velocity key 3-14 RS-232C interface

4. Material selection

- 4.1 The instrument has to be switched on by the Power- key 3-4.
- 4.2 The Material selection key 3-5 has to be pressed and the display 3-2 will show the code `cdxx` or `xxxx`. `cd` is the abbreviation for `code` and `xx` is a number among 0.1 and 11 that stands for the material to be measured as shown in the scale below.
 `xxxx` is a 4-digit number describing
- the sound velocity of the material defined by the user.

The `cdxx` material relationship is as follows:

Nr.	Code	Material
1	cd01	Steel
2	cd02	Cast iron
3	cd03	Aluminium
4	cd04	Red copper
5	cd05	Brass
6	cd06	Zinc
7	cd07	Quarz glass
8	cd08	Polyethylen
9	cd09	PVC
10	cd10	Grey cast iron
11	cd11	Nodular cast iron
12	XXXX	Sound velocity



Sauter GmbH Ziegelei 1 D-72336 Balingen E-Mail: info@sauter.eu

Tel: +49-[0]7433-9933-199 Fax: +49-[0]7433-9933-149 Internet: www.kern-sohn.com

Instruction Manual TD US

4.3 The Plus key 3-6 or the Minus key 3-9 is to be pressed to select the material code to measure. Then the Material selection key 3-5 is to be pressed to confirm.

The instrument changes into the measuring mode and on the display occurs $\ensuremath{`0`}$.

If a material code is selected without confirming this selection, the instrument will automatically change back into the measuring mode after a few seconds. In this case the primary material code will still be stored before switching off.

- 4.4 A 4-digit number will be shown on the display by pressing the Plus key 3-6 when displaying `cd11` or the Minus key 3-9 is to be pressed when displaying `cd01`. The 4-digit number is the last sound velocity being defined by the user. By changing the velocity, varying qualities of materials can be compensated.
- 4.5 If the material code has once been selected and saved it is stored in the memory of the instrument. As long as no modification is done, the instrument will always raise (use) this material code.
- 4.6 To get into the menu selection of the material code, the Material selection key 3-5 is to be pressed. To quit the menu the material selection key is to be pressed again or it has to be waited until the instrument- after a few seconds- changes back into the measuring mode. On the display appears `0`.

5. Calibration

- 5.1 A little oil is to be dropped on the base plate 3-12.
- 5.2 The calibration key 3-8 is to be pressed and `CAL` appears on the display.`CAL` is the abbreviation for calibration.
- 5.3 The sensor 3-7 is to be pressed on the base plate. The coupling symbol ((•)) (measurement in action) occurs if the measuring procedure has been established successfully by the process of sound sending and receiving.
 On the display appears`5.0mm` or 0.197 inch

(debit thickness of the base plate) and `CAL` in turn.

As soon as the value is stabilized, the `CAL` key 3-8 is to be pressed to confirm. Then the instrument changes back into the measuring mode.

5.4 The calibration has been finished and automatically saved in the instrument.

6. Measuring procedure

- 6.1 The Power key 3-4 is to be pressed to switch on the instrument.
- 6.2 The mm/ inch key 3-3 is to be pressed to select the correct measurement unit.
- 6.3 The sensor 3-7 is to be placed onto the material surface to be measured, provided that the material code has been selected correctly.
 Assure yourself that coupling is fine and the symbol ((•)) 3-11 is active. The measurement result is to be shown on the display.

- 6.4 The measurement result is saved until a new measurement is performed. The last value is conserved on the display until the instrument is switched off.
- 6.5 The instrument can be switched off by the Power- on/ Power- off key or by Auto-Power off function, one minute from last key operation.

7. Measuring by velocity setting

7.1 By pressing the VEL- key 3-13, on the display appears last saved velocity.

7.2 Measuring of coatings & materials by a known thickness:

Velocity can be adjusted by pressing the Plus- or the Minus- key. By doing this, the value shown on the display is changed higher or lower. First the increase is 10m/ s. If the Plus- or Minus- key is pressed for longer than 4 seconds, the increase is 100m/ s.

7.3 A little oil is to be dropped onto the material to be measured. Now the sensor 3-7 is pressed onto the surface to be measured. The reading on the display is the thickness, assumed that coupling is well.

If velocity of a special material is known, it is easy to measure the thickness with the help of step 7.2.

7.4 Measuring of coatings & materials with an unknown thickness:

A test material of known thickness is to be selected. Step 7.2 (vel.setting) and 7.3 is to be repeated until the measured value is exactly the same as the known thickness. In this case the set value is the velocity of the material to be measured. With this, any number of unknown thicknesses of the same material can now be measured.

- 7.5 To change velocity, VEL- key 3-13 is to be pressed. To return into the measuring mode, this key is to be pressed again or it has to be waited until the instrument automatically shows `0`.
- 7.6 By using velocity measurement, the coating thickness or the thickness of any hard materials can easily be measured.

8. Battery replacement

- 8.1 If the battery symbol appears on the display, batteries should be replaced.
- 8.2 The battery cover is to be removed from the instrument and the batteries are to be taken off.
- 8.3 Batteries are to be installed, paying carefully attention to polarity.



Sauter GmbH Ziegelei 1

D-72336 Balingen E-Mail: info@sauter.eu Tel: +49-[0]7433-9933-199 Fax: +49-[0]7433-9933-149 Internet: www.kern-sohn.com

Instruction Manual TD_US

9. Declaration of conformity



SAUTER GmbH D-72458 Albstadt E-Mail: Info@sauter.eu

Tel: 0049-[0] 7431- 938-666 Fax: 0049-[0] 7431-938-292 Internet: www.sauter.eu

Konformitätserklärung

Declaration of conformity for apparatus with CE mark Konformitälserklärung für Geräte mit CE-Zeichen Déclaration de conformité pour appareils portant la marque CE Declaración de conformidad para apparatos con marca CE Dichiarazione di conformità per apparecchi contrassegnati con la marcatura CE

English	We hereby declare that the product to which this declaration refers conforms with the following standards.

- Deutsch Wir enklären hiermit, dass das Produkt, auf das sich diese Enklärung bezieht, mit den nachstehenden Normen übereinstimmt.
- Français Nous déclarons avec cela responsabilité que le produit, auquel se rapporte la présente déclaration, est conforme aux normes citées ci-àprés.
- Español Manifestamos en la presente que el producto al que se refiere esta declaración est"a de acuerdo con las normas siguientes
- Italiano Dichiariamo con ciò che il prodotto al quale la presente dichiarazione si riferisce è conforme alle norme di seguito citate.

Thickness Gauge: SAUTER TD 225.01 US

Mark applied	EU Directives	Standards
CE		EN 61326 : 1997+A1 : 1998+A2 : 2001 EN 55022 EN 61000-4-2 /-3

Date: 07.01.2009

SAUTER GmbH, Schumannstrasse 33, D-72458 Albstadt, Tel: +49 (0) 7431 938 666, Fax: +49 (0) 7431 938 292

Seite 1 von 1

TVS SDW-CE-defai-0312