

# Welcome

KANE458s Flue Gas Analyser with direct CO, CO<sub>2</sub> & CO sensor protection

Quick reference guide



# Hello KANE458s getting started


- 1 Know your KANE458s
- 2 Connections
- 3 Before use
- 4 KANE ASSET MANAGEMENT (KAM)

Please register your analyser at www.kane.co.uk & download the full instruction manual from our product selector

## PLEASE READ ALL SAFETY WARNINGS IN THE MANUAL



Icon	Description
(II)	Data hold - Short press to hold current data on screen
$lackbox{}$	Pump toggle - Long press to toggle pump on & off
	Navigate Up - Short press to scroll up
1	Enter key - Used to select current option
	Navigate Down - Short press to scroll down
	Save log - Long press to store data
<b>*</b>	Print report - Short press to print a report



# 3 Before use

#### Check

Particle filter is not dirty; Water trap & flue probe empty of water; Water trap & red plug fitted to analyser; Flue probe hose connected to flue gas inlet; Flue probe temperature plug connected to T1 temperature connection

## Fresh air purge

Position flue probe in fresh air & press "On/Off" Analyser auto-calibrates within 60 seconds Select "Ratio" on dial - in fresh air CO reading = 0ppm Select "O2/Eff" on dial - in fresh air O2 reading = 20.9% Select "Status" on dial to view

## For best pressure sensor accuracy

Switch analyser on for 5 minutes to let temperature stabilise Zero pressure sensor when analyser in exact position of use

#### To charge NiMH rechargeable batteries

Switch off Connect charger - charging indicator illuminates Display shows "BATTERY CHARGING" if batteries need charging





## **KANE ASSET MANAGER (KAM)**





# Register your KANE analyser to create your KAM dashboard:

- ★ Simple online booking on www.kane.co.uk
- ★ Relevant product specific promotions, special offers & discounts
- ★ Automatic reminder when due for recertification
- ★ FREE POSTAGE returning your KANE analyser
- ★ SAME DAY annual FGA recertification OR YOUR MONEY BACK\*

\*Excludes KANE '9 series' analysers & UKAS certificates





Please register your analyser at www.kane.co.uk & download the full instruction manual from our product selector

#### PLEASE READ ALL SAFETY WARNINGS IN THE MANUAL





**Customer Service** 

0800 059 0800

Outside UK Call +44 1707 375550

Email: sales@kane.co.uk

#### Northern Customer Service Kane International Ltd

Gibfield Park Avenue, Atherton, Manchester, M46 0SY, UK Email: nservice@kane.co.uk

#### Southern & International Customer Service Kane International Ltd

Kane House, 11 Bessemer Road, Welwyn Garden City, Hertfordshire, AL7 1GF, UK Email: sservice@kane.co.uk



